

Screw Removal Made Easy

Many a mechanic has busted his knuckles and lost his temper while trying to remove blade tip caps. You claim a painful victory after you bust your knuckles, strip screw threads, destroy screw driving heads or scratch and gouge the cap and blade.

Save your knuckles and blade tip cap screws by using a screw extractor. Extractor, NSN 5120-01-398-2869, removes screws from size 8-32 through 1/4 inch. Extractor, NSN 5120-01-398-2868, removes 1/4-in through 3/8-in screws.

These extractors work on all aircraft panels and tip caps. Your commander must authorize their purchase since they are Class II items with a standard unit price that exceeds \$100.

